

## RG Colorado 2017-2021 Fitting Instructions.

Hi,

Thank you for your purchase of the RG Colorado 2017-2021\_Bash Plates.

With your purchase of the Stainless Steel plates, make sure the plates fit before removing the protective film. If your plates don't fit or have any other problem, the protective film needs to stay in tacked in order to receive a replacement set or a refund.

We have included a variety of bolts, and across the year ranges the bolt holes remained the same but the bolts may have changed. The bolt threads in the chaisee are 1.25 fine pitch thread. The 30mm M10's supplied with nut plates are a standard thread not to be used in the chaisee. This will only be valid with three piece sets, not for two piece sets.

### Front and Sump Plates

Our front plates are design to replace the models with the black plastic plates, not designed for models with silver tin plates. Please ensure you check this before removing factory plates. Start with the sump plate. This will go directly under the motor with the forks to the front. The back of the plate will share the bolts with the front of the transmission plate. When installing the front plate, line up the back of the plate with the front of the sump plate and use the same bolts. This will line the front of the plate to the existing holes. Always overlap front to back.

### Transmission Plate

Nut plate needs to be inserted inside the transfer cross member to give a thread for the transmission. The transmission plate will share the bolts of the sump plate and will use the 2x 30mm bolts to connect plate to the nut plates.

Thank You for your purchase

Simon Crowe