

VIEW FROM FRONT SIDE




FITTING PROCEDURE

- 1. ORIENTATE YOURSELF WITH EACH GUARD AND WHERE THEY WILL BE MOUNTED
- 2. LOCATE THE MOUNTING HOLES FOR THE SCREWS BY TEST FITTING EACH GUARD
- 3. HOLDING A GUARD ON THE SHOCK MOUNT, LOOSELY FIT SCREW TO ONE OF THE BOTTOM HOLES TO ALLOW IT TO ROTATE AND MOVE UP & DOWN
- 4. SLIDE A NUT PLATE INSIDE THE SHOCK MOUNT & LOOSELY BOLT UP TOP HOLE
- 5. SLIDE TWO MORE NUT PLATES INSIDE SHOCK MOUNT & LOOSELY BOLT UP MIDDLE HOLES
- 6. FOR BOTTOM HOLES, USE TWO SMALL WASHERS IN THE LARGE HOLE IN THE SHOCK MOUNT AS PACKERS THEN LARGE WASHERS ON THE OUTSIDE WITH SCREW AND NYLOC LOCK NUT, AS PER THE BOTTOM HOLE ARRANGEMENT DIAGRAGM
- 7. ALIGN AND SQUARE UP GUARDS AND PROCEED TO TIGHTEN ALL BOLTS AND NUTS

VIEW FROM BACK SIDE





BOTTOM HOLE ARRANGEMENT

PACKAGE CONTENTS

LEFT HAND SHOCK GUARD x1
RIGHT HAND SHOCK GUARD x1
NUT PLATES x6
M10x30 SCREW x10
SMALL M10 WASHER x10
LARGE M10 MUDGUARD WASHER x12
M10 SPRING WASHER x6
M10 NYLOC LOCK NUT x4

APPROX. WEIGHT - 4.2KG

	UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN						DRAWN	RICHARD BELL			DRAWING No.	
							CHECKED		ASSEMBLY AND BOLT DETAILS	A1	NUMBER COA-007	REV.
NOMINAL SIZE		UP TO 50	ABOVE 50	ABOVE 150	ABOVE 300 UP TO 1000	ABOVE 1000	APPROVED		CUSTOM OFFROAD ACCESSORIES TOYOTA LANDCRUISER 200 SERIES SHOCK GUARDS ASSEMBLY		CUSTOMER	
NOWIIVAL SIZ	-L		UP TO 150	UP TO 300			DATE APP'D				PROJECT	
MACHINING	+	0.1	÷. 0.2	÷. 0.3	÷. 0.5	÷ <u> </u>	SCALE	1:1.5	ASSEMBLY DETAILS		CAD FILE	
FABRICATIO	FABRICATION + 0	+ _. 0.5	+ 0.5	+ 0.5	÷. 1.0	+_ 2.0		DO NOT SCALE IF IN DOUBT ASK			COA-007-Toyota Landcruiser 200 Series Shock Guards Assembly	
ASSEMBLIES	S +	0.5	÷. 0.5	+ <u> </u>	÷. 1.0	÷. 2.0			ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED This drawing and any information or descriptive matter set out hered and copyright property of CUSTOM OFFF and must not be disclosed, loaned, copied or useful or manufacturing or for any other purpose without their written permission.	M OFFROAD ACCESSORIES		